




Powering Lives,
Empowering
Communities
www.solslife.com


Breeze Lite-S1 User Manual



What's in the Box

16-inch DC Stand Fan x1; Charge Cable x1

01 Installation Instructions:



01

Insert the connecting
rod into the chassis
mounting bracket.



02

Insert the fan
body into the
connecting rod.




03

Ensure the screw
holes are properly
aligned.




04

Tighten the screws
securely.



05

Align the mesh cover,
install it, and twist to
lock it in place.



06

Install the fan
blades onto the
motor shaft.



07

Secure the fan
blades firmly in
position.



08

Install the
front grille.




09

Tighten the screws
to secure both the front
and rear mesh covers.

02 Specification:

Accessories	Information
Fan	16-inch DC fan
Motor	Brushed Motor
Power	18W
Voltage	12V DC
Charge Cable	DC Cable
Port	DC5521
High Speed Mode	1875 rpm/<18W
Mid Speed Mode	1650 rpm/16.5W
Low Speed Mode	1470 rpm/15W

03 Product Introduction



04 Note :

Movement

- ⚠ When moving, be sure to stop the console and unplug it.
- ⚠ Hold the fan pillar firmly to avoid falling and injuring people.

Installation

- ⚠ Be sure to install this product correctly according to the instructions. Otherwise, electric shock, fire, personal injury, or other damage may occur.
- ⚠ If the fan is not assembled, do not turn it on.

During use

- ⚠ If the product has abnormal noise, odor, high temperature, inconsistent fan rotation frequency, etc., please stop using it immediately.
- ⚠ Do not lean on the fan and do not tilt the fan during operation.
- ⚠ Do not manually swing the machine head repeatedly, as this may damage the internal transmission mechanism.

Power cord

- ⚠ Before performing maintenance work or moving the fan, disconnect the power adapter from the AC outlet.
- ⚠ When disconnecting the power adapter, do not pull on the power cord.
- ⚠ If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or a qualified technician to avoid hazards.

05 Warning:

Improper use may result in electric shock, fire, personal injury, or other damages.

- ⚠ Do not use this product near objects that are unstable or prone to tipping.
- ⚠ Do not use this product in hot or humid environments, such as bathrooms.
- ⚠ Do not use this product if the power cord is damaged or the power plug is loose.
- ⚠ Do not operate this product if the front grille is not installed or if the rear grille is loose or detached.
- ⚠ Do not allow children or adults who do not understand this instruction manual to operate this product.
- ⚠ Do not disassemble or repair this product without authorization.
- ⚠ Do not excessively twist, bend, or pull the AC power cord, as this may expose or damage the internal wires.
- ⚠ Do not insert fingers or foreign objects into the front grille, rear grille, or moving fan blades.
- ⚠ Do not place hair, fabrics, or other objects near the fan, as they may become entangled and cause injury.
- ⚠ Do not use an improper or incompatible AC outlet.
- ⚠ Do not use the power adapter provided with this product for any other device.