




Powering Lives,
Empowering
Communities
www.solslife.com

Solar Radio Pro SRP1




What's in the Box
Radio x1; Type-C charge cable x1



01 Specification:

Accessories	Information
Operating Temperature	0.5 W / 1.0 W
Operating Voltage	2.7 V ~ 4.2 V
Operating Temperature	-10 °C ~ +60 °C
Battery	3.7V / 2000 mAh Lithium
Flashlight	1W 3 level LED Flashlight
Frequency Range	AM 520-1700 kHz FM 87-108 MHz WB 162.40-162.55 MHz

02 Labelling of functional areas:



01




03 Function:

- One or three bright white LED
- FM/AM/WB/SOS
- Emergency Phone Charging
- Discharging protection
- Power options:
Hand crank for manual power
Solar charging under sunlight
USB 5V charging via computer or adapter
- Water Resistance: IPX3


02

04 Using The Radio:

Turn the VOLUME dial clockwise to turn the radio on and control volume, and the green tune indicator LED light will be on



Select AM, FM, WB with radio band, For better reception, extend the RADIO ANTENNA



Turn TUNER DIAL to select station..



Long press the flashlight button to activate SOS mode with the flashlight flashing accordingly. Short press the button to turn it off.



03

05 Using The Flashlight:

The flashlight has three lighting modes: High, Medium, and Low. Press the button to turn it on, then press the button again to cycle through High, Medium, and Low modes until the flashlight turns off.



06 Solar/Handcrank/USB Power:

A Solar Power


Place product in average sunlight for approximately 10-12 hours, the red POWER INDICATOR illuminates when charging.



04

B Handcrank Power

- 1 Hand-crank Power
- 2 Lift the hand-crank
- 3 Hand-crank either
- 4 turn the hand-crank for one minutes (crank speed = 130 rmp)



C USB Port Charging

Insert one end of the charging cord into the USB-C jack and the other end into a computer USB port or a DC 5V adapter to charge the radio. The red power indicator will flash while charging and remain on when fully charged.




05

07 Charging Phone, PDA, MP3:

- 1 Lift the rubber tab on the side of the unit.



- 2 Insert the USB cable into the USB Jack and the other End to the device to be charged.



08 Charge & Discharge Protection:

- When the battery is overloaded or short-circuited, output will stop automatically.
- When the battery voltage drops below 2.7 V, the power output will automatically shut off.

06

09 Care And Maintenance:



Gently pull out the antenna for better reception and retract it properly when not in use.



Wipe the outside of the unit with a soft, damp cloth.



Clean the lens with a standard lens cleaning product.



Do not clean unit with harsh abrasive or any solvents.



The unit is not fully waterproof. It is rated IPX3 only. Do not submerge in water.



When the unit has been idle for over 60 days. Please hand crank or sunlight recharge for 3 to 5 minutes To activate the internal battery.

07